




# Sony Cyber-Shot DSC-W830 Flash Board Replacement

How to replace the flash board unit

Written By: Tong Tang



## INTRODUCTION

In order to reach the flashboard unit inside the device you have to first remove the front and back panel, the button board and the top cover of the device.

---



### TOOLS:


- [Phillips #000 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Battery




- Slide the lock at the bottom of the camera to "Open".
- ⓘ The door to the battery pack is spring loaded.

## Step 2



- Slide the blue clip up and away from the battery.

## Step 3



- Remove the battery.



## Step 4 — Front and Back Panel



- Remove the six 3.5mm Phillips #000 screws.
- Rotate the lock away from the camera.






## Step 5



- Pry the device open with the plastic opening tool.

**i** There are two clips that help prevent the front panel from separating.

## Step 6




- Remove the two plastic spacers between the front and the back panels.

**i** The spacers may fall out when removing the panels.

- Carefully remove the back panel.


## Step 7 — Button Board



- Gently release the button board from the clips.

**i** Be careful when lifting the button board; the ribbon cable will still be attached.


## Step 8



- Disconnect the no-fuss ribbon cable by gently pulling it out of the button board.




## Step 9 — Flash Board



- Gently pry the flash board up from its clips.

## Step 10



- Gently pull out the no-fuss ribbon cable from the flash board.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 02:12:26 AM.